



FIXTURE ASSEMBLY:

- Using the MOUNTING PLATE (A) as a template, mark the holes for the THREADED ROD (I) (BY OTHERS). NOTE: THREADED ROD (I), WASHER (J), NUT (K) (BY OTHERS) must be a minimum of 1/4" and affixed to the building structure following local building codes.
- Attach the NIPPLE (E) onto the MOUNTING PLATE (A), adjust the thread of the NIPPLE (E) so that it extends 1/2" beyond the CANOPY (L). Secure using HEX NUTS (F).
- Attach the HEADLESS BOLT (G) onto the MOUNTING PLATE (A), adjust the thread of the HEADLESS BOLT (G) so that it extends 1/2" beyond the BRACKET of the CANOPY (L). Secure using HEX NUTS (H).
- Install the MOUNTING PLATE (A) onto the junction box using the MOUNTING SCREWS (B) and THREADED ROD (I), WASHER (J), and NUT (K). This fixture is designed to be mounted on a heavy duty junction box rated for a minimum 90 lbs. The junction box must be securely mounted to the structure of the building. Pull the wire out from the junction box.
- Mount the CANOPY (L) onto NIPPLE (E) and HEADLESS BOLT (G), secure using HEX NUTS (F & H).
- Once your desired height is met cut off extra CHAINS (O), then attach the CHAINS (O) to the FIXTURE ASSEMBLY (Q) and CANOPY (L) using QUICK LINK (P). Feed the wire through the CHAIN (O) and CANOPY (L).
- Attach the SAFETY CABLE (T) to the building structure or brace using CABLE CLIP (U).
- Attach the Ground wire to the ground inside the junction box (Generally green or bare copper wire) or the GROUND SCREW (C) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Connect the fixture's SPT Neutral (SPT WIRE WITH NO WRITINGS) wire lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT (D)). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OR STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- Connect the fixture's SPT hot (SPT WITH WRITINGS) wire lead to the hot (Generally black) wire in the junction box. Fasten the joined wire same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRE. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Push the wires back into the junction box. Lift up the CANOPY (L) to the ceiling, attach the CAP (M) and secure with CENTER LOCK UP (N).
- Screw the BULB (R) into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR 10 WATT LED TYPE B11 LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- Hang the GLASS (S) into the FIXTURE ASSEMBLY (Q).
- Restore power to the outlet at the breaker or fuse box.

⚠ WARNING/CAUTION

- DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.
- TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL APPLICABLE NATIONAL AND LOCAL ELECTRICAL/BUILDING CODES. THE INSTALLATION AND MAINTENANCE OF THIS UNIT SHOULD BE COMPLETED BY A LICENSED ELECTRICIAN OR CERTIFIED FACTORY TRAINED TECHNICIAN.
- CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER USE.
- UNPACK FIXTURE, PARTS AND PARTS BAG(S) BEFORE DISCARDING THE CARTON. MAKE CERTAIN THAT ALL PARTS ARE FOUND. INSPECT THE FIXTURE PRIOR TO INSTALLATION FOR ANY DAMAGE. FIXTURE MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED. SEE WARRANTY FOR EXCEPTIONS.
- PLEASE CLEAN WITH A SOFT, DRY CLOTH ONLY! DO NOT USE CLEANSERS.