



**IMPORTANT**

Before using your Carroll 9FT Pre-Lit Flocked Garland, make sure that you carefully read through these instruction sheets.


**NOTE:** The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors that cannot be built into any product. This approach must be used by the person(s) caring for and operating the garland.

**GENERAL INFORMATION**

The garland is suited for indoor use only. DO NOT attempt to replace or repair any damaged cable parts. After use, ensure the garland is clean and dry before storage. DO NOT DISPOSE IN FIRE. Please dispose at your local recycling facility.


**STEP BY STEP INSTRUCTIONS**

Before using your garland, remove packaging. When setting up your garland, carefully position cables to avoid a tripping hazard.



**WHAT WE PROVIDE**


- Carroll 9FT Pre-Lit Flocked Garland
- Plug-in Power Supply



1

**STYLE YOUR GARLAND**


The branches on the garland come tightly packed for shipping. Separate and style the branches for your desired look.



2

**HANG YOUR GARLAND**


Select a location with a power outlet closeby. Be sure that the garland is hung or placed securely to support the weight of the garland.



3

**PLUG IN THE GARLAND**


Insert the plug into your wall outlet to illuminate the garland.



4A

**HOW TO EXTEND THE GARLAND**


Should you purchase additional garlands, you may wish to connect them together. Before connecting, be sure that all garlands are unplugged. Find the female connector at the end of the original garland. Remove the plug from the additional garland.



4B

**HOW TO EXTEND GARLAND CONT.**


Connect the female connector at the end of the original garland to the male connector at the beginning of the lead wire on the additional garland



4C

**HOW TO EXTEND GARLAND CONT.**

Insert the plug from the original garland into your wall outlet. Both garlands should now be illuminated.



4D

**HOW TO EXTEND GARLAND CONT.**

To give the illusion of one continuous garland, wrap the lead wire around itself and position in the branches to conceal.

NOTE: The garland can be connected up to a total of 3 individual garlands. DO NOT connect more than 3 garlands together at any time.