Lights
.com

IMPORTANT

Before installing your Lights.com fixture, please make sure that you carefully read through these instruction sheets. Consider having your fixture installed by a qualified licensed electrician.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the fixture.

GENERAL INFORMATION

All electrical connections must be made in accordance with all ordinances, and Local and National Electrical Codes. These fixtures are intended for mounting to a standard 4" junction box. The box must be directly supported by the building structure and be ETL or U.L. recognized.

STEP BY STEP INSTRUCTIONS

Before starting your installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. Just turning the light off at the light switch is not sufficient to prevent electrical shock.

COLLECTION	APPLICATION	MODEL NO.
Carter	Outdoor Flush Mount	LC005423

WHAT WE PROVIDE

- Ceiling Light
- Mounting & Wiring Hardware

WHAT YOU NEED

- Ladder
- Wiring Supplies as Specified by Electrical Code
- Electrical Tape
- 1 x E26 Bulb (60W Max)

1

UNPACK YOUR FIXTURE

Carefully set aside all parts and pieces.

2

PREPARE FIXTURE AND MOUNTING PLATE

Remove the Phillips head screws from the sides of the canopy, unscrewing counter-clockwise. This will remove the mounting plate from the fixture.

3

INSTALL THE MOUNTING PLATE

If there is an existing fixture, remove it. Expose the supply wires from the J-Box. Insert supply wires through the mounting plate. Secure the mounting plate using the Phillips head screws provided. Tighten to secure.


4

MAKE WIRE CONNECTIONS

Connect the BLACK fixture wire to the BLACK supply wire and the WHITE fixture wire to the WHITE supply wire. Connect the fixture ground wire to the J-BOX ground wire or wrap around one of the protruding screws on the mounting plate. Secure all connections with the supplied wire nuts and electrical tape (not supplied).

5

CONNECT FIXTURE TO THE MOUNTING PLATE

Lift the canopy up to the mounting plate, making sure to align the holes in the canopy with the holes in the mounting plate. Using the screws you removed in Step 2, secure the fixture to the mounting plate, turning clockwise to secure.

6

INSTALLING THE SHADE

Position the shade over the socket, and secure the shade using the threaded ring that was removed in Step 2. Turn the ring clockwise around the socket to secure in place.

7

INSTALL BULB

Install the E26 bulb (60W Max).
DO NOT EXCEED THE WATTAGE AS STATED ON THE WARNING LABEL.

8

RESTORE THE ELECTRICITY AND CHECK THE OPERATION OF YOUR NEW FIXTURE

CAUTION Please ensure that the fitting is cool and switched off before replacing the bulb. DO NOT use bulbs that might exceed the maximum wattage, stated on caution label.