

# **ASSEMBLY AND MOUNTING INSTRUCTIONS**

#### **GENERAL**

- WARNING-DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. TURN OFF THE ENTIRE ELECTRICAL CIRCUIT TO WHICH THE LIGHTING FIXTURE IS ATTACHED
- INSTALLATION AND MAINTENANCE OF THIS FIXTURE SHOULD BE COMPLETED BY A LICENSED ELECTRICAN
- FAILURE TO INSTALL FIXTURE CORRECTLY COULD RESULT IN SERIOUS INJURY OR DEATH
- READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION.
- IF AN EXISTING FIXTURE IS BEING REPLACED, REMOVE IT AND NOTE TO WHICH WIRE IN THE OUTLET BOX THE ORIGINAL FIXTURE WAS ATTACHED.
- BEFORE DISCARDING THE CARTON DOUBLE CHECK THE PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN FOUND.
- THIS FIXTURE WAS DESIGNED TO BE MOUNTED TO AN OCTAGON OUTLET BOX. THE BOX MUST BE SECURELY MOUNTED TO THE STRUCTURE OF THE BUILDING.

#### **INSTALLATION**

- Pull the wires out from the outlet box, and install mounting plate onto the outlet box using the (2) mounting screws.
- Fasten bare ground wire to ground wire from the wall outlet box (usually green or copper color) or connect ground wire to green screw on the mounting plate.
- Connect the neutral (white) fixture wire coming from the fixture base to neutral (usually white) outlet wire. Fasten both wires together with a plastic wire nut and tightly wrap the wire nut with electrical tape.
- Repeat the previous step with the hot (black wires). Make sure there are no exposed wires or strands that could cause a dangerous short circuit.

- FAILURE TO CONNECT THE APPROPRIATE WIRES CORRECTLY COULD RESULT IN SERIOUS INJURY OR DEATH!
- 5. Carefully place connections back into the outlet box
- 6. Place canopy over the mounting plate and secure with set screws.
- nstall the lamp(s). The H368601S is rated for a 25 watt G9 xenom lamp, the H368601M is rated for a 40 watt type A15 lamp, the H368601L is ratef for a 60 watt type A15 lamp.
  DO NOT EXCEED RECOMMENDED WATTAGE!
- Lift the glass shade up and twist onto the light fixture to secure in place.
- 9. Restore power to the circuit at breaker or fuse box.

### **DIMMING**

The fixture can be controlled by a wall dimming device. Only use triac/electronic dimmer. Make sure carton is marked for use with LED compact fluorescent-incandescent light source only. These can be


provided by your local electrical distributor, home center, or hardware store.

### CLEANING

Please clean with a soft, dry cloth NOLY! Do not use cleaning products.



## **ASSEMBLY AND MOUNTING DIAGRAM**



## WIRE NUT/TAPING DIAGRAM

