


FLORA
6 LIGHT
LINEAR CHANDELIER 50"
MODEL NO. LC006215,
LC006216



## WARNING/CAUTION

- DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE
  STARTING INSTALLATION.
- TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL APPLICABLE NATIONAL
  AND LOCAL ELECTRICAL/BUILDING CODES. THE INSTALLATION AND MAINTENANCE OF THIS UNIT SHOULD BE
  COMPLETED BY A LICENSED ELECTRICIAN OR CERTIFIED FACTORY TRAINED TECHNICIAN.
- CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO
  CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER USE.
- UNPACK FIXTURE, PARTS AND PARTS BAG(S) BEFORE DISCARDING THE CARTON. MAKE CERTAIN THAT ALL PARTS ARE
  FOUND. INSPECT THE FIXTURE PRIOR TO INSTALLATION FOR ANY DAMAGE. FIXTURE MAY NOT BE RETURNED ONCE IT
  HAS BEEN INSTALLED. SEE WARRANTY FOR EXCEPTIONS.
- PLEASE CLEAN WITH A SOFT, DRY CLOTH ONLY! DO NOT USE CLEANSERS.

## **FIXTURE INSTALLATION**

- 1. Feed the wire through the STEM (L) and twist tightly onto the FIXTURE ASSEMBLY (N). Keep adding additional stems until your desired hanging height is met.
- 2. Attach the NIPPLE (G) onto the STEM (L) then insert the CHECK RING (H) onto the NIPPLE (G). Attach the CANOPY (I) on top of the STEM (L), and secure using HEX NUTS (K) and TOOTH WASHER (J).
- 3. Pull the wire out from the junction box, and install the MOUNTING PLATE (A) onto the junction box using the MOUNTING SCREWS (B). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building. Thread the MOUNTING NIPPLE (C) unto the MOUNTING PLATE (A), adjust its threads so that <sup>3</sup> " of threads extend beyond the CANOPY (I), secure using MOUNTING HEX NUTS (D).
- 4. Trim off the excess wire to a minimum 6" beyond the STEM (L) and strip each wire 5".
- 5. Attach the Ground wire (Green) to the ground inside the outlet box (Generally green or bare copper wire) or the GROUND SCREW (E) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- 6. Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (F). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- Connect the black fixture leads to the hot (Generally black) wire in the outlet box. Fasten the joined wires same as
  previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS
  INJURY OR DEATH!
- 8. Push the wires back into the junction box. Lift up the CANOPY (I) up to the ceiling, and secure with the CAP NUT (M).
- Screw the BULB (O) into the SOCKET of the FIXTURE ASSEMBLY (N). THIS FIXTURE IS RATED FOR 60 WATTS TYPE B LAMP (G16.5 RECOMMENDED). DO NOT EXCEED THE RECOMMENDED WATTAGE!
- 10. Restore power to the outlet at the breaker or fuse box.