



FIXTURE ASSEMBLY:

- Using the MOUNTING PLATE (A) as a template, mark the holes for the THREADED ROD (K) (BY OTHERS). NOTE: THREADED ROD (K), WASHER (L), NUT (M) (BY OTHERS) must be a minimum of 1/4" and affixed to the building structure following local building codes.
- Screw the NIPPLE (E) to the MOUNTING PLATE (A). Adjust the thread of the NIPPLE (E) so that its thread extends 1/2" beyond the CANOPY (L) (USE THE CANOPY AS A GUIDE) and secure using LOCK WASHER (G) and HEX NUT (F).
- Pull the wires out of the junction box. Install the MOUNTING PLATE (A) onto the junction box using the MOUNTING SCREWS (B) and THREADED ROD (K), WASHER (L), and NUT (M). This fixture is designed to be mounted on a heavy duty junction box rated for a minimum 90 lbs. The junction box must be securely mounted to the structure of the building.
- Mount the CANOPY (H) onto the NIPPLE (E) then secure using LOCK WASHER (I) & HEX NUT (G).
- Open the end links of CHAIN (O) then attach to the FIXTURE ASSEMBLY (P) and CANOPY (H). Add, and remove chain until your desired hang height is met. Feed the wire through the CHAIN (O), CANOPY (H), and MOUNTING PLATE (A).
- Attach the SAFETY CABLE (U) to the building structure or brace using CABLE CLIP (V).
- Attach the Ground wire to the ground inside the junction box (Generally green or bare copper wire) or the GROUND SCREW (C) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Connect the fixture's SPT Neutral (SPT WIRE WITH NO WRITINGS) wire lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT (D)). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OR STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- Connect the fixture's SPT hot (SPT WITH WRITINGS) wire lead to the hot (Generally black) wire in the junction box. Fasten the joined wire same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRE. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Push the wires back into the junction box. Lift up the PLATE (S) up to the ceiling and secure with FINIAL (N).
- Screw the BULB (Q) into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR 10 WATT TYPE B11 LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- Hang the GLASS (R) into the FIXTURE ASSEMBLY (P).
- Restore power to the outlet at the breaker or fuse box

⚠ WARNING/CAUTION

- DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.
- TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL APPLICABLE NATIONAL AND LOCAL ELECTRICAL/BUILDING CODES. THE INSTALLATION AND MAINTENANCE OF THIS UNIT SHOULD BE COMPLETED BY A LICENSED ELECTRICIAN OR CERTIFIED FACTORY TRAINED TECHNICIAN.
- CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER USE.
- UNPACK FIXTURE, PARTS AND PARTS BAG(S) BEFORE DISCARDING THE CARTON. MAKE CERTAIN THAT ALL PARTS ARE FOUND. INSPECT THE FIXTURE PRIOR TO INSTALLATION FOR ANY DAMAGE. FIXTURE MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED. SEE WARRANTY FOR EXCEPTIONS.
- PLEASE CLEAN WITH A SOFT, DRY CLOTH ONLY! DO NOT USE CLEANSERS.